049103/049104/049105/049106/049108/049109/049112/049113/ 049114/049118/049120/049124/049125/049126/049127/049128/ 049130/049131/231310/231311/

READ CAREFULLY BEFORE INSTALLING

CAUTION: Piston to cylinder wall clearance must be checked before installing new cylinders.
For correct clearance refer OEM workshop manual specifications or specifications given by piston manufacturer