ASSEMBLY SHEET EXHAUST **DYNA** WITH ELECTRONIC VARIABLE SOUND

P.S .: These mufflers are designed to be installed on the specific motorcycle.

1- remove the seat

2- remove the original exhaust system according to the manufacturer's instructions

3- remove the original manifold and heat cover (only for MCJ short mufflers with manifold)

4- install MCJ exhaust system

5- check all alignments before tightening the screws

6- position the motor braket under the regulator

7- match the two holes on the chassis with the two holes on the motor brakes

8- fix the motor

9- take the fuse attached, cut the wire in half (picture 2)

10- connect the positive of the black box with the fuse and connect it to the battery

11- connect the negative of the black box to the battery

12- position the black box under the seat safe

13- fix the wires with the motor’s chain (picture 1)

14- che the valves into the mufflers: they will be one open and one close

15- insert wires into the slots of the motor and tighten the nuts

16- connect the black box jack with the motor jack

17- take the remote control and press A or B to check the motor

18- adjust the position of the valves with the registers on the mufflers cables

19- close the motor with his cover

20- refit the seat



PICTURE1



PICTURE2