301869
OIL FILTER HOUSING COVER

MOUNTING INSTRUCTIONS

1. Installation must be performed with a cold engine. We recommend installing this cover in the evening, permitting the silicone adhesive used in step 3 to cure overnight before starting the engine.

2. Clean the filter housing with degreaser (housing must absolutely free of grease and dirt)

3. Using silicone adhesive provided with the cover, put smooth, even 1/4" long beads on the inside of the cover. Do not use an excess, only a small amount is required.

4. Carefully slide the cover over the oil filter housing. Gently push the cover on to the housing. Clean away any excess silicone that may have squeezed out during installation.

5. Allow motorcycle to sit cold for 12 hours (overnight) to permit silicone to cure before start up.